

Test of smooth running control

Test of smooth running control

Instructions

- Wait until the correction values for smooth running control are displayed correctly.

Note

- Pressing button 'Reset' sets the correction values to zero.

Cylinder 1	-0.53%
Cylinder 2	10.00%
Cylinder 3	-2.00%
Cylinder 4	-1.37%
Cylinder 5	-1.48%
Cylinder 6	-4.68%

Reset

Continue

MB_LKW/Steuergeraete/Antrieb/MCM/MR201T/MR201T.gmf#Pruefungen/Laufzeit/Menueauswahl_Pruefungen