



DAIMLER TRUCK

Legend:

- A57 (NOx sensor control unit, exhaust aftertreatment unit outlet)
- A57 b1 (NOx sensor, exhaust aftertreatment unit outlet)
- A70 (NOx sensor control unit, exhaust aftertreatment unit inlet)
- A70 b1 (NOx sensor, exhaust aftertreatment unit inlet)
- B72 (Exhaust temperature sensor upstream of SCR catalytic converter)
- B73 (Exhaust temperature sensor downstream of SCR catalytic converter)
- R8 (AdBlue® pressure line heating element)
- A57 (NOx sensor control unit, exhaust aftertreatment unit outlet)
- A57 b1 (NOx sensor, exhaust aftertreatment unit outlet)
- A70 (NOx sensor control unit, exhaust aftertreatment unit inlet)
- A70 b1 (NOx sensor, exhaust aftertreatment unit inlet)
- B72 (Exhaust temperature sensor upstream of SCR catalytic converter)
- B73 (Exhaust temperature sensor downstream of SCR catalytic converter)
- R8 (AdBlue® pressure line heating element)

Instructions

- Replace component 'A70 (NOx sensor control unit, exhaust aftertreatment unit inlet)'.